

V10-R User Manual



READY AIM FIRE



V10-R User Manual

TABLE OF CONTENTS

Safety

Parts

Operation

Maintenance

Troubleshooting



V10-R SAFETY




Please read and understand the safe use of this product. This is a flame throwing device so treat it as if it was a firearm. Failure to use this product safely may result in death, injury property damage and unintentional fires.

1. Treat this product like a firearm.
2. Aim it away from anything you don't want to destroy.
3. When not in use remove the battery
4. Store in a well ventilated area away from furnaces, fireplaces, water heaters or anything flammable
5. Never touch the electrodes or nozzle during use.
6. Do not use if wind is present.
7. Remove the battery when refueling
8. Do not put any part of your body in front of the unit when in use.
9. Only operate outdoors.
10. Only the recommended fuel sources should be used, never use napalm.
11. Never transport with the battery in and fuel in the unit.
12. Never spray the unit higher than a 45 degree angle. Fuel could drip or land on the operator.
13. If any leaks are noticed discontinue use immediately.
14. Never operate this product under the influence of drugs or alcohol.
15. Tipping the unit side to side will cause fuel leakage.



V10-R PARTS

1. On/off switch
2. Trigger
3. Battery holder
4. Electrodes
5. Fuel tank
6. Front handle
7. Carry handle
8. Guard



Operation

1.

The battery that comes with your V10-R will need to be charged before your first use.



Operation

2.

On a flat surface remove the cap from the fuel tank. Fill the tank so the fuel level is a half inch below the opening. Be careful not to over fill. Wipe off any spilled fuel. Screw the cap on firmly.

Only use straight gasoline(any octane/ethanol) OR 60% gasoline 40% diesel

Never use napalm homemade or commercial available

Always add a fuel stabilizer to your gas can. Any brand will work, Stabil, Seafoam.



Operation

3.

Install the battery and switch the power button to on. Aim in a safe direction and squeeze the trigger. A stream of fuel will spray out and the electrodes will arc igniting the stream.

If you have be spraying it is common for a small flame to form on the tip of the nozzle. Give a minute and it will go out.

When finished turn the unit off and remove the battery.





Maintenance and Storage



4.

Maintenance is easy with the V10-R. Keep the unit clean, wipe down the outside and with soapy and water or simple green.

Wipe off the guard and electrodes to remove carbon and soot.

Inspect for leaks before every use.

We recommend using the V10-R once every 3 month or once a quarter. This device is made to be used. The worst thing is for it to set without use for long periods. This can cause the pump to stop working.

Store with the unit off and the battery removed and fuel tank empty. Store inside but away from anything flammable. If left in the elements it may cause the body to discolor or break.

Troubleshooting

<p>Power is on nothing happens when the trigger is pressed</p>	<ul style="list-style-type: none">• Battery must have at least 10 volts• Check trigger isn't broken
<p>Fuel isn't igniting completely</p>	<ul style="list-style-type: none">• Fuel has moisture in it• Too much diesel fuel• Electrodes out of alignment
<p>Nozzle always on fire when using</p>	<ul style="list-style-type: none">• Electrodes interfering with stream
<p>Nozzle drips occasionally</p>	<ul style="list-style-type: none">• This is normal, open the fuel cap and release all pressure